



CUIDADO PESSOAL  
TRATAMENTO CORPORAL



SABONETE DE MÃOS  
AMARELO SUAVE  
[MP-03]

# SABONETE DE MÃOS AMARELO SUAVE [MP-03]

PHASE	INCI	BRAND NAME	CONCENTRATION [%]	FUNCTION
A	Aqua		46,55	solvente
	Potassium Oleate		8,00	surfactante
	Sodium Lauroyl Glycinate	ROKAtend GL	25,00	surfactante
	Decyl Glucoside		7,00	surfactante
B	Citric acid		0,20	modificador de pH
C	Parfum		0,50	fragrância
	Benzy Alcohol, Ethylhexylglycerin, Tocopherol		1,00	conservante
	Cocamidopropyl Betaine	ROKamina®K30	10,00	surfactante
	Sodium Chloride		1,75	modificador de viscosidade



pH		8.5 - 9.0
Aparência	método visual	líquido amarelo
Viscosidade [cP]	Brookfield LV, fuso 34, velocidade 2,5 RPM, T: 25°C	3000 - 5000
estabilidade	1 mês a 5°C, RT, 40°C	confirmado

## Procedure:

1. No recipiente grande (grande o suficiente para fornecer mistura adequada durante a preparação do lote), despeje água deionizada.
2. Adicione os ingredientes da fase A ao recipiente enquanto mistura. Aquecer até 70 - 75°C. Misture até obter uma solução homogênea.
3. Resfrie o lote até pelo menos 35°C.
4. Ajuste o pH para 8,5 - 9,0 usando ácido cítrico. Misture bem após o ajuste.
5. Adicione fragrância, conservante e Cocamidopropyl Betaine. Misture até obter uma solução homogênea.
6. Se necessário, adicione cloreto de sódio para ajustar a viscosidade. NOTA: é muito importante equilibrar uma amostra a 25°C por pelo menos uma hora para obter uma medição precisa da viscosidade.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform to check full range of products for personal care.

[www.products.pcc.eu](http://www.products.pcc.eu)

PCC Group  
Sienkiewicza 4  
56-120 Brzeg Dolny  
Poland

e-mail: [products@pcc.eu](mailto:products@pcc.eu)

