



PENJAGAAN DIRI
PRODUK PENCUKUR

LOSYPEN SELEPAS CUKUR [KD-147]



LOSYEN SELEPAS CUKUR [KD-147]

PHASE	INCI	BRAND NAME	CONCENTRATION [%]	FUNCTION
A	Cetearyl Alcohol and Cetareth-20	EXOcare®TE20 FLAKES	4,0	pengemulsi
	Glycine Soja Oil		1,0	emolien
	Dimethicone		1,0	emolien
	PPG-15 Stearyl ether	ROKAnol® SP15L	2,0	emolien
B	Aqua		83,8	pelarut
	Betaine		1,0	aktif
	Allantoin		0,1	aktif
C	Carbomer		0,2	pengubahsuai reologi
	PPG-15 Stearyl ether	ROKAnol® SP15L	0,5	emolien
	Cyclopentasiloxane		1,0	emolien
D	Sodium Hydroxide		0,1	pelaras pH
E	Phenoxyethanol, Ethylhexylglycerin		0,8	bahan pengawet
F	Aluminum Starch Octenylsuccinate		1,0	penyerap
	Parfum		0,5	wangian
G	Alcohol		3,0	pelarut



pH	5.0 - 7.0	
Penampilan	kaedah visual	emulsi putih
Kestabilan	1 bulan pada 5°C, 20°C, 40°C	disahkan

Procedure:

1. Dalam bekas berasingan gabungkan bahan-bahan dari fasa A dan B. Panaskan sehingga 75-80°C
2. Masukkan fasa A ke fasa B semasa mengadun. Homogenkan 60-90 saat. Dalam bekas yang berasingan satukan bahan dari fasa C. Gaul sehingga sekata.
3. Sejukkan batch hingga 60°C semasa mengadun. Masukkan bahan fasa C dan D semasa mengadun. Homogenkan dengan 2500-3500 RPM, 90 saat.
4. Sejukkan batch hingga 40-50°C semasa mengadun. Masukkan bahan fasa D, E dan F semasa mengadun. Homogenkan dengan 2500-3500 RPM, 90 saat. Sejukkan batch hingga 30°C semasa mengadun.
5. Masukkan fasa F dan G semasa mengadun. Homogenkan dengan 2500-3500 RPM, 90 saat



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

