



KIŞİSEL BAKIM
VÜCUT BAKIMI



İÇ HİJYEN İÇİN KÖPÜK
[KD-07]

İÇ HİJYEN İÇİN KÖPÜK [KD-07]

PHASE	INCI	BRAND NAME	CONCENTRATION [%]	FUNCTION
A	Aqua		kadar	çözücü
	Glycerin		4,00	nemlendirici ajan
	Magnesium Laureth Sulfate	EXOsoft MG	4,00	süfaktan
	Disodium Laureth Sulfosuccinate	EXOsoft L3 / 40	4,00	süfaktan
	Betaine		0,50	aktif
	Sodium Benzoate, Potassium Sorbate		0,50	koruyucu
	Lactic Acid		q.s.	pH ayarlayıcı
B	Panthenol		0,10	aktif
	PEG-120 Methyl Glucose Dioleate		0,25	kalinlaştırıcı
C	Cocamidopropyl Betaine	ROKamina®K30	2,00	süfaktan
	Parfum		0,20	koku



pH		4.0 - 4.5
görünüm	görsel yöntem	görsel yöntem parlak sarı
istikrar	5°C'de 1 ay, oda sıcaklığında, 40°C	onaylanmış

Procedure:

- Bir ana kapta A fazındaki malzemeleri birleştirin. A fazındaki malzemeleri ılık suya (40-45°C) ekleyin. Üniforma kadar karıştırın.
- PEG-120 Metil Glikoz Dioleat ve Panthenol ekleyin. Üniforma kadar karıştırın. Partiyi en az 30°C'ye soğutun.
- Karıştırma sırasında Cocamidopropyl Betaine ve Parfum ekleyin. Üniforma kadar karıştırın.
- Gerekirse, pH'ı Laktik Asit ile 4,0 - 4,5'e ayarlayın.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

