



CUIDADO PESSOAL  
TRATAMENTO FACIAL

## MÁSCARA FACIAL [KD-120]



# MÁSCARA FACIAL [KD-120]

PHASE	INCI	BRAND NAME	CONCENTRATION [%]	FUNCTION
A	Ceteareth-12	ROKAnol®T12	2,0	emulsificante
	Ceteareth-25	ROKAnol® T25	0,5	emulsificante
	Cetearyl alcohol	Flocos ExoAlc 1618	3,0	estabilizador de emulsão
	PPG-15 Stearyl ether	ROKAnol® SP15L	5,0	emoliente
	Caprylic/Capric Triglyceride		5,0	emoliente
	Glycine Soja Oil		2,5	emoliente
	Stearic Acid		1,0	modificador de reologia
	Tocopheryl Acetate		0,5	ativo
	Butyrospermum Parkii Butter		1,0	emoliente
B	Aqua		71,5	solvente
	Pentylene Glycol		2,5	solvente
	Betaine		1,0	ativo
	Magnesium Aluminum Silicate		1,0	modificador de reologia
C	Kaolin		3,0	absorvente
	Phenoxyethanol, Methylparaben, Ethylparaben, Propylparaben		0,5	conservante



<b>pH</b>		5.0 - 7.0
<b>Aparência</b>	método visual	emulsão levemente cinza
<b>estabilidade</b>	1 mês a 5°C, RT, 40°C	confirmado

## Procedure:

1. Em um recipiente principal, combine os ingredientes da fase B. Adicione Pentileno Glicol, Betaína à água. Adicione o Silicato de Alumínio e Magnésio enquanto mistura. Homogeneizar com 2000–3000 RPM, 5–6 min.
2. Em um recipiente separado, misture os ingredientes da fase A.
3. Aqueça as fases A e B a 75–80°C.
4. Adicione A em B, enquanto mistura, mantenha A/B a 75–80°C. Homogeneizar com 2000–3000 RPM, 120 seg.
5. Resfrie o lote até 50°C enquanto mistura. Adicione os ingredientes da fase C enquanto mistura. Homogeneizar com 2500–3500 RPM, 120 seg.
6. Arrefecer o lote até 25°C.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform to check full range of products for personal care.

[www.products.pcc.eu](http://www.products.pcc.eu)

PCC Group  
Sienkiewicza 4  
56-120 Brzeg Dolny  
Poland

e-mail: [products@pcc.eu](mailto:products@pcc.eu)

