



PERSONLIG VÅRD  
HÅRBEHANDLING



KLASSISKT SCHAMPO  
[SZ-01]

# KLASSISKT SCHAMPO [SZ-01]

PHASE	INCI	BRAND NAME	CONCENTRATION [%]	FUNCTION
A	Aqua		37,95	lösningsmedel
	PEG-7 Glyceryl Cocoate	rokacet-ko300g	2,00	återoljningsmedel
	Disodium Laureth Sulfosuccinate	sulfobursztynian-13-40	4,00	tensid
	Sodium Laureth Sulfate	SULFOROKAnol® L227/1	30,00	tensid
	Sodium Lauroyl Sarcosinate	ROKAtend LS	15,00	tensid
B	Citric acid		0,05	pH-modifierare
C	PEG-120 Methyl Glucose Dioleate		1,00	förtjockningsmedel
D	Parfum		0,50	doft
	Ethylhexyl Glycerine, Phenoxyethanol		1,00	konserveringsmedel
	Cocamidopropyl Betaine	ROKamina®K30	4,50	tensid
E	Sodium Chloride		1,50	viskositetsmodifierare



pH		5.0 - 7.0
Utseende	visuell metod	grumlig gel
Viskositet [cP]	Brookfield LV, spindel 34, hastighet 2,5 rpm, T: 20°C	1500 - 5000
Stabilitet	1 månad vid 5°C, RT, 40°C	bekräftad

## Procedure:

1. Tillsätt ingredienser från fas A till det varma vattnet (70-75°C).
2. Tillsätt ingredienserna efter varandra under blandningen i ordningen enligt tabellen ovan. Blanda tills det är enhetligt.
3. Kyl satsen till minst 50°C.
4. Kontrollera pH-intervallet. Justera vid behov pH med citronsyra till 5,0 - 7,0.
5. Tillsätt PEG-120 Methyl Glucose Dioleate under blandning. Blanda tills det är enhetligt. Kyl satsen till minst 35°C.
6. Tillsätt doft, konserveringsmedel och Cocamidopropyl Betaine under blandningen. Blanda tills det är enhetligt.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform to check full range of products for personal care.

[www.products.pcc.eu](http://www.products.pcc.eu)

PCC Group  
Sienkiewicza 4  
56-120 Brzeg Dolny  
Poland

e-mail: [products@pcc.eu](mailto:products@pcc.eu)

