



PERSOONLIJKE VERZORGING
LICHAAMSBEHANDELING



SCHUIM VOOR INTIEME
HYGIËNE [KD-07]

SCHUIM VOOR INTIEME HYGIËNE [KD-07]

PHASE	INCI	BRAND NAME	CONCENTRATION [%]	FUNCTION
A	Aqua		tot	oplosmiddel
	Glycerin		4,00	vochtinbrengend middel
	Magnesium Laureth Sulfate	exosoft-mg	4,00	oppervlakactieve stof
	Disodium Laureth Sulfosuccinate	EXOsoft L3/40	4,00	oppervlakactieve stof
	Betaine		0,50	actief
	Sodium Benzoate, Potassium Sorbate		0,50	conserveermiddel
	Lactic Acid		q.s.	pH-regelaar
B	Panthenol		0,10	actief
	PEG-120 Methyl Glucose Dioleate		0,25	verdikkingsmiddel
C	Cocamidopropyl Betaine	Cocamidopropyl Betaine	2,00	oppervlakactieve stof
	Parfum		0,20	geur



pH		4.0 - 4.5
Uiterlijk	visuele methode	visuele methode heldergeel
stabiliteit	1 maand bij 5°C, KT, 40°C	bevestigd

Procedure:

1. Combineer ingrediënten uit fase A in een hoofdvat. Voeg ingrediënten uit fase A toe aan warm water (40-45°C). Meng tot uniform.
2. Voeg PEG-120 methylglucosediolaat en panthenol toe. Meng tot uniform. Koel de batch af tot minimaal 30°C.
3. Voeg Cocamidopropyl Betaine en Parfum toe tijdens het mixen. Meng tot uniform.
4. Pas indien nodig de pH met melkzuur aan op 4,0 - 4,5.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

