



KIŞISEL BAKIM
TIRAŞ ÜRÜNLERİ

TIRAŞ SONRASI LOSYON [KD-147]



TIRAŞ SONRASI LOSYON [KD-147]

PHASE	INCI	BRAND NAME	CONCENTRATION [%]	FUNCTION
A	Cetearyl Alcohol and Ceteareth-20	EXOcare®TE20 FLAKES	4,0	emülgatör
	Glycine Soja Oil		1,0	yumuşatıcı
	Dimethicone		1,0	yumuşatıcı
	PPG-15 Stearyl ether	ROKAnol® SPI5L	2,0	yumuşatıcı
B	Aqua		83,8	çözücü
	Betaine		1,0	aktif
	Allantoin		0,1	aktif
C	Carbomer		0,2	reoloji değıştirici
	PPG-15 Stearyl ether	ROKAnol® SPI5L	0,5	yumuşatıcı
	Cyclopentasiloxane		1,0	yumuşatıcı
D	Sodium Hydroxide		0,1	pH ayarlayıcı
E	Phenoxyethanol, Ethylhexylglycerin		0,8	koruyucu
F	Aluminum Starch Octenylsuccinate		1,0	emici
	Parfum		0,5	koku
G	Alcohol		3,0	çözücü



pH		5.0 - 7.0
görünüm	görsel yöntem	beyaz emülsiyon
istikrar	5°C, 20°C, 40°C'de 1 ay	onaylanmış

Procedure:

1. A ve B fazındaki malzemeleri ayrı kaplarda birleştirin. 75-80°C'ye kadar ısıtın
2. Karıştırırken faz A'yı faz B'ye ekleyin. Homojenize 60-90 sn. Ayrı bir kapta faz C'deki malzemeleri birleştirin. Homojen olana kadar karıştırın.
3. Karıştırırken partiyi 60°C'ye soğutun. Karıştırırken faz C ve D bileşenlerini ekleyin. 2500-3500 RPM, 90 sn ile homojenize edin.
4. Karıştırırken partiyi 40-50°C'ye soğutun. Karıştırırken faz D, E ve F bileşenlerini ekleyin. 2500-3500 RPM, 90 sn ile homojenize edin. Karıştırırken partiyi 30°C'ye soğutun.
5. Karıştırırken faz F ve G'yi ekleyin. 2500-3500 RPM, 90 sn ile homojenize edin



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

