



PERSONLIG VÅRD
KROPPSBEHANDLING



TVÅFAS SKUMMANDE
ANSIKTSTVÄTT [ST-05]

TVÅFAS SKUMMANDE ANSIKTSTVÄTT [ST-05]

PHASE	INCI	BRAND NAME	CONCENTRATION [%]	FUNCTION
A	Aqua		38,4	lösningsmedel
	Sodium Lauroyl Glycinate	ROKAtend GL	10,0	tensid
	Sodium Lauroyl Sarcosinate	ROKAtend LS	30,0	tensid
	Propylene Glycol		3,0	lösningsmedel
	Parfum		0,6	doft
	Ethylhexyl Glycerine, Phenoxyethanol		1,0	konserveringsmedel
	PEG-7 Glyceryl Cocoate	rokacet-ko300g	1,6	återoljningsmedel
	Mineral Oil		15,0	uppmjukande
	Citric acid		0,4	pH-modifierare



pH		6.0 - 7.5 (water phase)
Utseende	visuell metod	klar, färglös vätska
Stabilitet	1 månad vid 5°C, RT, 40°C	bekräftad

Procedure:

1. Tillsätt ingredienser från fas A till det varma vattnet (40-50°C). Blanda tills det är enhetligt.
2. Kyl sedan blandningen till rumstemperatur innan du tillsätter ett konserveringsmedel och tillsätt resten av ingredienserna.
3. Kontrollera pH-intervallet – tillsätt citronsyra om det behövs. Blanda väl efter justering.
4. Tillsätt natriumklorid för att justera viskositeten. NOTERA. Tillsätt salt (inte på en gång) – efter tillsats av varje portion blanda väl.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

