



OSOBNÁ STAROSTLIVOSŤ
OŠETRENIE TEĽA



PENA PRE INTÍMNU
HYGIENU [KD-07]

PENA PRE INTÍMNU HYGIENU [KD-07]

PHASE	INCI	BRAND NAME	CONCENTRATION [%]	FUNCTION
A	Aqua		do	solventný
	Glycerin		4,00	hydratačný prostriedok
	Magnesium Laureth Sulfate	exosoft-mg	4,00	povrchovo aktívna látka
	Disodium Laureth Sulfosuccinate	EXOsoft L3/40	4,00	povrchovo aktívna látka
	Betaine		0,50	aktívny
	Sodium Benzoate, Potassium Sorbate		0,50	konzervačný prostriedok
	Lactic Acid		q.s.	upravovač pH
B	Panthenol		0,10	aktívny
	PEG-120 Methyl Glucose Dioleate		0,25	zahusťovadlo
C	Cocamidopropyl Betaine	Cocamidopropyl Betaine	2,00	povrchovo aktívna látka
	Parfum		0,20	vôňa



pH		4.0 - 4.5
Vzhľad	vizuálna metóda	vizuálna metóda svetložltá
Stabilita	1 mesiac pri 5 °C, RT, 40 °C	potvrdil

Procedure:

1. V hlavnej nádobe zmiešajte ingrediencie z fázy A. Pridajte ingrediencie z fázy A do teplej vody (40-45°C). Miešajte, kým nebude jednotná.
2. Pridajte PEG-120 metylglukózodioleát a pantenol. Miešajte, kým nebude jednotná. Násada sa ochladí aspoň na 30 °C.
3. Počas miešania pridajte Cocamidopropyl Betaine a Parfum. Miešajte, kým nebude jednotná.
4. Ak je to potrebné, upravte pH kyselinou mliečnou na 4,0 – 4,5.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

